

FIG. 1




FIG.2

USER ID	PAPER SIZE	SUBSTITUTE PAPER SIZE	ZOOM
00000001	LT	A4	x
	B5	A4	○
	B4	A3	○
00000002	LT	A4	x
	LG	B4	x
00000003	FREE (200 × 280)	A4	x
	FREE (180 × 260)	A4	x

FIG.3

APPARATUS NAME	APPARATUS INFORMATION
Printer 1	RICOH Aficio AP3200
Printer 2	RICOH Aficio AP2700
Printer 3	RICOH Aficio AP2222

Select

↑

↓

FIG.4

APPARATUS NAME	APPARATUS INFORMATION
Printer 1	RICOH Aficio AP3200
Printer 2	
Printer 3	

USER ID

OK

Cancel

Select

↓

FIG.5

APPARATUS NAME Printer 1		
PAPER SIZE	SUBSTITUTE SIZE	ZOOM
LT	A4	×
B5	A4	○

↑

↓

Add

Change

Delete

OK

Cancel

FIG.6

APPARATUS NAME Printer 1		
PAPER SIZE	SUBSTITUTE SIZE	ZOOM
PAPER SIZE:	B5	▲▼
SUBSTITUTE SIZE:	A4	▲▼
ZOOM :	ㄥ	

↑

↓

OK

Cancel

OK

Cancel

FIG.7

PAPER SIZE:	<input type="text" value="FREE"/>	▲▼
SUBSTITUTE SIZE:	<input type="text" value="A4"/>	▲▼
ZOOM :	<input type="text"/>	
		<input type="button" value="OK"/> <input type="button" value="Cancel"/>

FIG.8

VERTICAL(mm) :	<input type="text"/>
HORIZONTAL(mm) :	<input type="text"/>
<input type="button" value="OK"/> <input type="button" value="Cancel"/>	

FIG.9

@psize_set
00000001:LT-A40,B5-A41,B4-A31
00000002:LT-A40,LG-B40
00000003:
@psize_end

FIG.10

PAPER CONVERSION SETTING	
USER ID	<input type="text"/>
<div>OK Cancel</div>	

FIG.11

PAPER CONVERSION SETTING		
SIZE	SUBSTITUTE SIZE	ZOOM
LT	A4	x
B5	A4	○
<div>↑</div>	<div>↓</div>	<div>OK</div>
		<div>Cancel</div>

FIG.12

PAPER CONVERSION SETTING		
SIZE	SUBSTITUTE SIZE	ZOOM
LT	A4	x
<div><input type="button" value="Add"/> <input type="button" value="Delete"/> <input type="button" value="Cancel"/></div>		

FIG.13

PAPER CONVERSION SETTING		
SIZE	SUBSTITUTE SIZE	ZOOM
<input type="text" value="LT"/>	A4	x
<input type="button" value="↑"/>	<input type="button" value="↓"/>	<div><input type="button" value="OK"/> <input type="button" value="Cancel"/></div>

FIG.14

PAPER CONVERSION SETTING		
SIZE	SUBSTITUTE SIZE	ZOOM
LT	<input type="text" value="A4"/>	x
<input type="button" value="↑"/>	<input type="button" value="↓"/>	<input type="button" value="OK"/>
		<input type="button" value="Cancel"/>

FIG.15

PAPER CONVERSION SETTING		
SIZE	SUBSTITUTE SIZE	ZOOM
LT	A4	<input type="text" value="x"/>
<input type="button" value="↑"/>	<input type="button" value="↓"/>	<input type="button" value="OK"/>
		<input type="button" value="Cancel"/>

FIG.16




FIG.17




FIG.18




FIG.19




FIG.20




FIG.21

The image shows a printer configuration window with a 'Normal Print Details' dialog box open. The main window has tabs for 'Setup', 'Paper', 'Print Quality', 'Statistics', and 'Water Marks'. The 'Setup' tab is active, showing various settings:

- Job Type:** Normal (dropdown)
- Copies:** 1 (text box)
- Details...** (button)
- Collate:** Off (checkbox)
- Orientation:** Portrait (dropdown)
- Layout:** 1 page per sheet (dropdown)
- Duplex:** Off (checkbox)
- Staple:** Off (checkbox)
- Help** (button)

The 'Normal Print Details' dialog box is open, showing:

- User ID:** (text box)
- Up to 8 alphanumeric (e.g. A-Z,0-9) characters** (text box)
- OK** (button)
- Cancel** (button)
- Help** (button)

The background window also displays a preview of a document and a list of paper sizes: A4(210 x 297mm), Input, Auto Tray Select, Plain, and Output.

FIG.22

^[%-12345X@PJL JOB NAME="abc"
@PJL COMMENT RPJL,WINNT4.0,PCL6,0.1.6,GRAYSCALE
@PJL SET USERID="00000001"
@PJL SET TIME="10:07:20"
@PJL SET DATE="2001/11/19"
@PJL SET TRACKID="AUIRWAAADc1DqWQ"

FIG.23

